

Standard Knapp Standard Knapp

an EMPLOYEE owned company

INFEED CASE STOPS

**UPGRADE FOR:
939 Case Packer**



Figure 1.1 - Location of Infeed Case Stops




Figure 1.2 - Close-up of Infeed Case Stops

Benefits

- Maintains positive case position on casefeed during an e-stop condition
- Case stops remain in a closed position while machine is at rest.
- Shortens downtime.
- Increases machine efficiency.

Call the Standard-Knapp Sales Department at
1-800-628-9565 ext. 239 for ordering information.

Standard-Knapp, Inc.
127 Main Street
Portland, CT 06480
1-800-628-9565
(fax) 860-342-0783
www.standard-knapp.com
info@standard-knapp.com

StandardKnapp StandardKnapp

an EMPLOYEE owned company




Figure 1.3 - Infeed Case Stop Installed on Case Packer




Figure 1.4 - Infeed Case Stop in OPEN position




Figure 1.5 - Infeed Case Stop in CLOSED position

SPECIFICATIONS

SPEED: No Limits

PRODUCT RANGE: Unchanged

AIR: Unchanged

CONTROLS: Unchanged

POWER: Unchanged

CONSTRUCTION: Stainless Steel, Hyfax plastic

ESTIMATED WEIGHT: 5 lbs.

INSTALLATION: Standard-Knapp installation Recommended

TIME TO INSTALL: 2 Hours

ADDITIONAL UPGRADE KITS AVAILABLE FOR YOUR 939 CASE PACKER

- DISCHARGE ROLLER ASSEMBLY
 - HEAVY DUTY LIFT TABLE
 - MINOR FLAP GUIDES
- QUICK CHANGE PRODUCT STOPS
 - REAR CASE CLAMP